



93	94	95
96	97	98
99	100	

Nr.	Omschrijving	Artikelnummer	Nr.	Omschrijving	Artikelnummer
1	O-Ring	XAM-E4006A	53	Grip (M10)	XAM-NH20041
2	Quadring	XAM-E4020C	54	Hex Nut	XAM-FM10P0
3	GARDENA Adapter G1/4"	XAM-F20150	55	O-Ring	XAM-E40110
4	Cover	XAM-F41295	56	Valve	XAM-F43343
6	Flow Adjustment	XAM-F43341	57	Toothed Lock Washer	XAM-FV04TV
7	Hex-Head Bolt	XAM-FB2030	58	Thermal Overcurrent Circuit Breaker	XAM-9Z3113
8	Cylinder Head Cap Screw	XAM-FBC816	59	Protective Cover	XAM-A50280
9	Washer	XAM-FS06C1	60	Earth Cable	XAM-6C6031
10	Washer	XAM-FS10Z0	61	Pan Head Screw	XAM-FZ4110
11	Washer	XAM-FS1200	62	Thermal Security Cables	XAM-6C6025
12	Countersunk screw	XAM-FZ0612	63	Handle (Both Sides)	XAM-NH1132
13	Grip	XAM-N14027	64	Suppression Capacitor	XAM-NH1137
14	Waterhose	XAM-N14081	65	Cable Clamp	XAM-NH1145
16	Bolt (metric fine 10.9 )	XAM-NH1101	66	Screw	XAM-NH1144
18	Cover Ø540 ( CARAT )	XAM-NH20017CA	67	Switch Motor Break	XAM-NH1136A
19	Cover Ø540 Assembly	XAM-NH20017CAC	68	Motor Control	XAM-NH1138
20	Main Flange Ø30mm	XAM-NH20020	69	Suppression Capacitor	XAM-NH1137A
21	Locking Flange	XAM-NH20021	70	Switch Knob	XAM-NH1135
22	Blade guard cover	XAM-NH20025	71	Safety Knob	XAM-NH1133
23	Spacer Seal	XAM-NH20026	72	Spring	XAM-NH1134
24	Spray Control	XAM-NH20032	73	Switch	XAM-NH1136
25	Clamping Sleeve	XAM-NH20033	74	Tule	XAM-NH1146
26	Shaft Seal Ring	XAM-E30A30	75	Cable Assembly incl. PRCD Black	XAM-6C6024CAX
27	Shaft Seal Ring	XAM-E30A32	75.1	Electrocable	XAM-6C6026
28	Deep Groove Ball Bearing	XAM-EA018A	75.2	Electrocable (T)	XAM-6C6028
29	Bearing	XAM-EA044A	75.3	PRCD SWITCH	XAM-9Q2026CA
30	Metal Shield	XAM-EXR103	76	Washer	XAM-FS0500
31	Wing Nut	XAM-F40015	77	Cylinder Head Cap Screw	XAM-FBC735
32	Kogelknop M8	XAM-F40131	78	Pan Head Tapping Screw	XAM-FF1425
33	Hexagon Socket Head Cap Screw	XAM-FBC716	79	Combi Screw	XAM-NH1167
34	Threaded Insert	XAM-FG0808	80	Motor Housing	XAM-NH1170
35	Threaded Insert	XAM-FG1212	81	Stator	XAM-NH1165ZW
36	Hexagon Socket Set Screw	XAM-FI0825	82	Carbon Brush	XAM-NH1169
37	Spring Retaining Ring	XAM-FR0120	83	Brush Holder Cap	XAM-NH1168
38	Retaining ring	XAM-FR1470	84	Spring Washer	XAM-FV05S0
39	Hexagon Socket Countersunk Screw	XAM-FV6016	85	Button Head Screw (PH)	XAM-FZ4290
40	Slip Lock	XAM-NH1120	86	Armature	XAM-NH1163ZW
41	Clutch Spring (Large)	XAM-NH1122	86.1	Insulation Ring	XAM-NH1172
42	Clutch Spring (Small)	XAM-NH1123	86.2	Bearing	XAM-EA007E
43	Gear M5143	XAM-NH1124ZW	87	Air Ring	XAM-NH1162
44	Locking Shaft	XAM-NH20006	88	Fan	XAM-NH1161
45	Main Shaft	XAM-NH20007	89	Bearing	XAM-EA026C
46	Gearbox	XAM-NH20013	90	O-ring	XAM-E4032B
47	Gearbox Cover	XAM-NH20016	91	Serial Plate W-5421	XAM-NH2S0003
48	Gasket	XAM-NH20019	92	Serial Protection	XAM-N140281
49	Coverplate	XAM-NH20029	93	Manual W-5421	XAM-NH2MAN09
50	Clamping Bus	XAM-NH20037	94	General Power Tool Safety Warnings	XAM-NMVX002
51	Bushing	XAM-NH20038	95	Machine Specific Safety Warnings	XAM-NMVX004
52	Rod ( depth )	XAM-NH20039	96	Instruction Sheet NL	XAM-NH2MAN03

Nr.	Omschrijving	Artikelnummer
97	Instruction Sheet EN	XAM-NH2MAN04
98	Instruction Sheet FR	XAM-NH2MAN05
99	Instruction Sheet DE	XAM-NH2MAN06
100	Wrench SW17	XAM-G1009L

Nr.	Omschrijving	Artikelnummer
-----	--------------	---------------